

ASSEMBLY INSTRUCTIONS

USA & CANADA

WARNING!

Be sure electrical power is OFF before and during installation or maintenance. The luminaire must be installed by a qualified electrician, in accordance with all applicable Ensure that the rated luminaire voltage requirements are compatible with the available mains supply in which it will be installed.

All LEDS are included in your lamp. Never touch the LED surface with your bear hands as this may reduce the life of your LED.

Do not alter, relocate or remove any electrical component




Material: Natural Wood Veneer, MDF, milky acrylic.


Turn OFF the electrical power before starting the installation, and keep it turned off until the installation is completed.

This assembly may require the work of two people so it can be secure and well executed.

- Remove the protecting package from the pieces taking care to not harm any parts with cutting surfaces or objects. Lay the parts of the fixture on some horizontal surface in order to connect them, if needed use the protecting package to soften the surface and protect the parts from getting scratched or harmed.
- (02) Next, pass the steel cables through the cable anchors fixed on the canopy (C). The support cable excess must go inside the
- (03) Adjust the height and the level of the pendant by pressing the lower tip of the cable anchors, next, roll or cut the steel cable excess. If the steel cables are cut, notice that the height adjustment will be limited.



PROVIDED SCREWS



ATENTION!



FAILURE TO COMPLY WITH THESE INSTRUCTIONS MAY CAUSE ACCIDENTS AND LOSS OF PRODUCT WARRANTY. Its recommended to read these instructions completely and carefully before proceeding

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

ACCORD Lighting guarantees coverage against manufacturing defects including electrical components and finishes, for a period of three years, under normal use, from the date of purchase. For warranty service, please contact your local dealer for further instructions. Proof of date of purchase will be required for validation of warranty service

The responsability of the manufacturer regarding the product warranty is related to the correct observation of the instructions contained in this manual. The manufacturer is not responsible for any damage to the product caused by accidents, alterations of any kind, improper usage or improper installation. See the website for additional warranty details.

ACCORD Lighting reserves the right to change the dimensions and specifications contained in this manual without prior notice, in accordance with its policy of continuous product improvement. Please, contact the manufacturer if additional information is necessary. The illustrations in this manual are for quidance only and may vary in scale, dimensions and model details



-01

ED III

Wattage

15W

18W

23W

25W

29W

32W

36W

23W

27W

29W

32W

36W

21W

29W

35W

42W

58W

69W

15W

18W

22W

25W

29W

32W

36W

21W

28W

35W

44W

58W

73W

ASSEMBLY INSTRUCTIONS

USA & CANADA

WARNING!

4

Ref.

1415

1437

1316

1317

1318

1319

1320

1349

1350

1351

1352

1353

1354

1355

1356

1357

1358

1359

1430

1431

1432

1433

1434

1435

1436

1449

1450

1451

1467

1468

1469

Be sure electrical power is OFF before and during installation or maintenance. The luminaire must be installed by a qualified electrician, in accordance with all applicable local codes.

Ensure that the rated luminaire voltage requirements are compatible with the available mains supply in which it will be installed.


All LEDS are included in your lamp. Never touch the LED surface with your bear hands as this may reduce the life of your LED.

Do not alter, relocate or remove any electrical component.

Input voltage: 120-277 V Input frequency: 60 Hz Isolation: Class II

Material: Natural Wood Veneer, MDF, milky acrylic.

MAKING ELECTRICAL CONNECTIONS



The cable from the pendant that enters the canopy was two internal wires, BLACK and WHITE.


The BLACK wire from the cable corresponds to the Positive terminal of the LED, and must be connected to the Positive wire coming from the driver, the RED wire.

The WHITE wire from the cable corresponds to the Negative , terminal of the LED, and must be connected to the Negative wire coming from the driver, the BLUE (or BLACK) wire.

- I Connect the <u>Positive</u> wire from the single cable (Black), to the <u>Positive</u> wire from the <u>Driver</u> (Red), using the marked (+) Wago connector.
- II Connect the <u>Negative</u> wire from the single cable (White), to the <u>Negative</u> wire from the <u>Driver</u> (Blue or Black), using the marked (-) Wago connector.
- (5) Using the white flat 3 core cable that exits the driver's enclosure, make the electrical connections to the mains supply, in accordance with all safety standards and local electrical codes. This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product, and the hazards involved.
- Ob Screw the junction box cover (J) and structural base (B) in the junction box using the provided screws (S1).
 - Once the structural base (B) is fixed in the ceiling, insert the excess energy cable in the junction box and fit the canopy (C) in the structural base, pushing it against the ceiling and rotating it until it locks. Fasten the provided screw (S2) to secure it.

Turn on the electrical power.

The luminaire is ready for use.



ATENTION!



FAILURE TO COMPLY WITH THESE INSTRUCTIONS MAY CAUSE ACCIDENTS AND LOSS OF PRODUCT WARRANTY. Its recommended to read these instructions completely and carefully before proceeding.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

ACCORD Lighting guarantees coverage against manufacturing defects including electrical components and finishes, for a period of three years, under normal use, from the date of purchase. For warranty service, please contact your local dealer for further instructions. Proof of date of purchase will be required for validation of warranty service.

The responsability of the manufacturer regarding the product warranty is related to the correct observation of the instructions contained in this manual. The manufacturer is not responsible for any damage to the product caused by accidents, alterations of any kind, improper usage or improper installation. See the website for additional warranty details.

ACCORD Lighting reserves the right to change the dimensions and specifications contained in this manual without prior notice, in accordance with its policy of continuous product improvement. Please, contact the manufacturer if additional information is necessary. The illustrations in this manual are for guidance only and may vary in scale, dimensions and model details.